


Ituo-Varia
SimpleSpec 200.102™

| Installation
Manual




Contents Overview

(×4)




3/8" Varia Panel

(×2)




3/8" Varia
Corner Panel

(×2)




Vertical Post,
1 Glazing Channel, 96"
0-15-2183

(×5)




Vertical Post,
2 Glazing Channels, 96"
0-15-2181

(×14)




1/2" Glazing Channel
3-15-2009

(×2)




Half Wall Top Cap
Straight Run, End

(×1)




Half Wall Top Cap
Straight Run

(×2)




Half Wall Top Cap
Corner

(×3)




Installation Template
Baseplate Guide
3-15-2160

(×4)




Installation Template
Spacer Guide
3-15-2347

(×2)




Installation Template
Corner Guide
3-15-2182

(×1)



VHB Tape
3-15-2171


Contents Overview



(×7)

Baseplate KIT
3-15-2110-K


=



(×7)

Baseplate
3-15-2110


+



(×14)


Baseplate
Cover
3-15-2114

+



(×14)


Screw
3-15-2308



(×7)

**Baseplate Universal
Anchoring KIT**
3-15-2119-K


=



(×28)


M8x105 Concrete
Lag Screw
3-15-2309

+



(×28)


Hex Head Wood
Lag Screw
3-15-2310



(×5)

**Half Wall Center Post
Attachment KIT**
3-15-2163-K


=



(×10)

Half Wall Top Rail Straight
Adapter Plate
3-15-2163


+



(×20)


Screw
3-15-2303

+



(×20)


Screw
3-15-2302



(×2)

**Half Wall End Post
Attachment KIT**
3-15-2164-K


=



(×2)

Half Wall Top Rail End
Adapter Plate
3-15-2164


+



(×8)

Screw
3-15-2303

+



(×4)


Screw
3-15-2302

3form

For more information, please visit 3-form.com or call 800.726.0126
SEPTEMBER 2022 | MAN-RTG-200-102-VARIA | REV 003 © 2022 3form, Inc. All rights reserved.

3


Overview




Required Tools




Drill



Hammer Drill




Rubber Mallet



Saw

a Baseplate templates (3-15-2160) will be provided. The baseplate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.



- b** Following the Iltuo Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


****3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.***

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310


Installation

2 Assemble Vertical Posts (×7)


- a** Cut Glazing Channel
(3-15-2009) to
3' 11 $\frac{1}{8}$ " lengths. (×12)



- b** Assemble Vertical Posts (0-15-2182). (×2)




Assemble Vertical Post (0-15-2181). (×5)




Installation

3 Secure First Vertical Post to Floor

Use hammer drill to secure post.




4 Install First Varia Panel




Installation

5 Secure Second Vertical Post




6 Install Corner Varia Panel




Installation

7 Install Remaining Posts and Panels



8 Install Adapter Plates on Posts



Installation

9 Install Top Caps

