


Ituo-Glass SimpleSpec 200.56™

Installation
Manual




Contents Overview




(×2)

Glass Panel




(×2)

Vertical Post,
1 Glazing Channel, 96"
0-15-2183




(×1)

Vertical Post,
2 Glazing Channels, 96"
0-15-2181




(×4)

½" Glazing
Channel
3-15-2009




(×3)

Half Wall Top Cap
Straight Run, End




(×2)

U Channel
0-15-2104




(×2)

Low Profile Glazing
Channel, 47"
0-15-2125




(×3)

Installation Template
Baseplate Guide
3-15-2160




(×2)

Installation Template
Spacer Guide
3-15-2347




(×3)

VHB Tape
3-15-2171




(×3)

Baseplate KIT
3-15-2110-K




(×3)

Baseplate
3-15-2110



(×6)




Baseplate Cover
3-15-2114




(×6)

Screw
3-15-2308


Contents Overview

<p>(×3)</p>  <p>Baseplate Universal Anchoring KIT 3-15-2119-K</p>	<p>(×12) + (×12)</p> <p>M8x105 Concrete Lag Screw 3-15-2309 Hex Head Wood Lag Screw 3-15-2310</p>
<p>(×1)</p>  <p>Half Wall Center Post Attachment KIT 3-15-2163-K</p>	<p>(×2) + (×4) + (×4)</p> <p>Half Wall Top Rail Straight Adapter Plate 3-15-2163 Screw 3-15-2303 Screw 3-15-2302</p>
<p>(×2)</p>  <p>Half Wall End Post Attachment KIT 3-15-2164-K</p>	<p>(×2) + (×8) + (×4)</p> <p>Half Wall Top Rail Straight Adapter Plate 3-15-2164 Screw 3-15-2303 Screw 3-15-2302</p>

Add a Set of 2 Panels


<p>(×2) Glass Panel</p> <p>(×2) U Channel 0-15-2104</p> <p>(×2) Low Profile Glazing Channel, 47" 0-15-2125</p> <p>(×2) Vertical Post, 2 Glazing Channels, 96" 0-15-2183</p> <p>(×4) ½" Glazing Strip, 96" 3-15-2009</p> <p>(×2) Baseplate KIT 3-15-2110-K</p> <p>(×2) Baseplate Universal Anchoring KIT 3-15-2119-K</p> <p>(×2) Installation Template Baseplate Guide 3-15-2160</p> <p>(×2) Installation Template Spacer Guide 3-15-2347</p> <p>(×2) Half Wall Center Post Attachment KIT 3-15-2163-K</p> <p>(×1) Half Wall Top Cap Straight Run</p>	
--	--

Overview




Installation

Required Tools



1 Drill Pilot Holes (×12)

- a** Baseplate templates (3-15-2160) will be provided. The Baseplate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.



- b** Following the Illtuo Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


**3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.*

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310


Installation

2 Assemble Vertical Posts (×3)


- a** Cut Glazing Channel
(3-15-2009 or
3-15-xxxx) to
3' 11¹/₈" lengths. (×12)



- b** Assemble Vertical Posts (O-15-2182). (×2)




Assemble Vertical Post (O-15-2181). (×1)




Installation

3 Secure First Vertical Post to Floor


Use hammer drill to secure post.



4 Assemble U Channel (x2)



Cut Glazing Channel (0-15-2125) to 3'9.25" length.




Insert Glazing Channel (0-15-2125) into U Channel (0-15-2104).


Installation

5 Install First Glass Panel

- a** With 2 people, orient the Glass Panel and lift it so that it is centered and fully seated in the U Channel. When fully seated, it should be difficult to remove the Glazing Channel and U Channel from the Glass Panel.




- b** Insert long edge of the Glass Panel into the Glazing Channel in the anchored Vertical Post. Use a block and mallet to ensure the exposed edge is vertically leveled. Rest the U Channel on the Base Plate.
Use best practices for glass installation.



6 Install Remaining Posts and Panels


Follow Steps 2-5 to install remaining Glass Panels and Vertical Posts.

Ensure that additional Vertical Posts are level and square so that the glass consistently extends above the posts $\frac{1}{4}'' - \frac{5}{16}''$. This is critical for the Top Rail engagement.



Installation

7 Install Adapter Plates on Posts



8 Install Top Caps

