



*Ituo-Varia*  
**SimpleSpec 200.57™**


| Installation  
Manual





Contents Overview


(×1)


(×2)


(×1)


(×2)


(×1)

(×4)


(×2)

(×1)


(×1)

(×2)


=

(×2)

+

(×2)

+

(×4)

Vertical Post, 1 Glazing Channel, 96"  
0-15-2183

Cantilever Top Rail, 96"  
0-15-2103

1/2" Glazing Channel  
3-15-2009

Low Profile Glazing Channel, 47"  
0-15-2125

Self-Tapping Screw  
3-15-2311

Installation Template Baseplate Guide  
3-15-2160

Installation Template Spacer Guide  
3-15-2347

VHB Tape  
3-15-2171

Baseplate KIT  
3-15-2110-K


Baseplate  
3-15-2110

Baseplate Cover  
3-15-2114

Screw  
3-15-2308

Contents Overview


(×2)



**Top Rail  
End Cap KIT**  
3-15-2116-K

=


(×2)



**Top Rail End Cap**  
3-15-2116

+


(×4)



**Top Rail Low Profile  
M6 T-Nut**  
3-15-2123


+

(×4)



**Screw**  
3-15-2312


(×2)



**Baseplate Universal  
Anchoring KIT**  
3-15-2119-K

=


(×8)



**M8x105 Concrete  
Lag Screw**  
3-15-2309

+

(×8)



**Hex Head Wood  
Lag Screw**  
3-15-2310

Add a Panel

(×1) 3/8" Varia Panel

(×2) 1/2" Glazing Channel 3-15-2009

(×1) Baseplate KIT 3-15-2110-K


(×4) Self-Tapping Screw 3-15-2311

(×1) Baseplate Universal Anchoring KIT 3-15-2119-K


(×1) Installation Template Baseplate Guide 3-15-2160

(×1) Installation Template Spacer Guide 3-15-2347

(×1) Vertical Post, 2 Glazing Channels, 96" 0-15-2181 →




Overview



Installation


Required Tools




Drill




Drill Bits



Hammer Drill



Rubber Mallet




Saw

1 Drill Pilot Holes (×8)

- a** Baseplate templates (3-15-2160) will be provided. The base plate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.

Installation Template  
Spacer Guide  
3-15-2347

Installation Template  
Baseplate Guide  
3-15-2160



- b** Following the Iltuo Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


*\*3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.*

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310


Installation

2 Assemble Vertical Posts (×2)

Assemble Vertical Posts (0-15-2182). (×2)




Assemble Vertical Post (0-15-2181). (Only for "Add a Panel")




3 Secure First Vertical Post to Floor

Use hammer drill to secure post.



**Installation**


**4** Install Varia Panel



**5** Install Second Vertical Post

Repeat Step 3 for the second vertical post.

**6** Connect Top Rail to Vertical Posts



**7** Attach End Caps

