


Ituo-Varia
SimpleSpec 200.101™

| Installation
Manual




Contents Overview


- (×3)




**3/8" Varia
Panel**
- (×2)




**3/8" Varia
Corner Panel**
- (×2)




**Vertical Post,
1 Glazing Channel, 96"**
0-15-2183
- (×4)




**Vertical Post,
2 Glazing Channels, 96"**
0-15-2181
- (×2)




**Cantilever
Top Rail, 96"**
0-15-2103
- (×7)




**Low Profile Glazing
Channel, 47"**
0-15-2125
- (×10)




1/2" Glazing Channel
3-15-2009
- (×12)




**Self-Tapping
Screw**
3-15-2311
- (×2)




**Installation Template
Baseplate Guide**
3-15-2160
- (×3)



**Installation Template
Spacer Guide**
3-15-2347
- (×2)





















**Installation Template
Corner Guide**
3-15-2182
- (×1)




VHB Tape
3-15-2171

Contents Overview


 <p>(×6)</p> <p>Baseplate KIT 3-15-2110-K</p>	 <p>(×6)</p> <p>Baseplate 3-15-2110</p> <p>+</p>  <p>(×12)</p> <p>Baseplate Cover 3-15-2114</p> <p>+</p>  <p>(×12)</p> <p>Screw 3-15-2308</p>
 <p>(×2)</p> <p>Top Rail End Cap KIT 3-15-2116-K</p>	 <p>(×2)</p> <p>Top Rail End Cap 3-15-2116</p> <p>+</p>  <p>(×4)</p> <p>Top Rail Low Profile M6 T-Nut 3-15-2123</p> <p>+</p>  <p>(×4)</p> <p>Screw 3-15-2312</p>
 <p>(×6)</p> <p>Baseplate Universal Anchoring KIT 3-15-2119-K</p>	 <p>(×24)</p> <p>M8x105 Concrete Lag Screw 3-15-2309</p> <p>+</p>  <p>(×24)</p> <p>Hex Head Wood Lag Screw 3-15-2310</p>
 <p>(×2)</p> <p>Cantilevered Top Rail Long Leg Mitered Corner KIT 3-15-2176-K</p>	 <p>(×2)</p> <p>Top Rail Mitered Corner Bracket 3-15-2118</p> <p>+</p>  <p>(×8)</p> <p>Top Rail Low Profile M6 T-Nut 3-15-2123</p> <p>+</p>  <p>(×8)</p> <p>Screw 3-15-2312</p> <p>+</p>  <p>(×4)</p> <p>Low Profile Glazing Channel Miter Corner 3-15-2183</p> <p>+</p>  <p>(×2)</p> <p>Top Rail Miter B Length 3-15-2177</p> <p>+</p>  <p>(×2)</p> <p>Top Rail Miter A Length 3-15-2176</p>

Overview




Installation

Required Tools



1 Drill Pilot Holes (×24)

- a** Baseplate templates (3-15-2160) will be provided. The baseplate template has hole locations for drilling. Spacers will also be provided, unique to this configuration; cut to size based off post dimensions in the quoting phase.



- b** Following the Iltuo Installation Template, drill pilot holes. Use appropriate pilot hole diameter and depth for the type of substrate you are fastening to.


**3form stocks the drill bits required for the concrete and wood pilot holes. If you wish to purchase a drill bit, please contact your 3form sales representative.*

Substrate	Ø	Drill Bit	Depth	Anchors
Concrete	8mm	3-15-2350	min 4.3"	3-15-2309
Wood	3/16"	3-15-2335	min 3.5"	3-15-2310


Installation

2 Assemble Vertical Posts (×6)

Assemble Vertical Posts (O-15-2182). (×2)




Assemble Vertical Post (O-15-2181). (×4)




3 Secure First Vertical Post to Floor

Use hammer drill to secure post.




Installation

4 Install First Varia Panel




5 Secure Second Vertical Post




Installation

6 Install Corner Varia Panel




7 Install Remaining Posts and Panels




Installation

8 Assemble Top Rail


- a** Cut Glazing Channel (0-15-2369) to the length of the Top Rail (0-15-2103).



b





c




d

- Cut Low Profile Glazing Channel (3-15-2183) into (×4) 23" long pieces, then insert into each end.



Installation

9 Connect Top Rail to Vertical Posts



10 Attach End Caps (×2)

